


☎ 0121 543 6200

🌐 www.rapidclimatecontrol.com

SAFETY & OPERATING GUIDE



MB50 COOLING FAN

BASIC SAFETY

Before using this equipment and to avoid personal injury, carefully read and understand these instructions. If there is anything you do not understand, DO NOT use this equipment, contact the hire company for advice.

Make sure you are aware of all safety requirements and that this equipment is suitable for the task you wish to undertake.

The work area must be cordoned off from the general public and bystanders.

This equipment must not be operated by persons who are under the influence of alcohol or drugs. Do not use this equipment if you are tired or unwell.

You MUST perform a risk assessment before using this equipment to ensure your safety and the safety of others.

This equipment must only be used by persons who are medically fit to do so. If you have any medical condition, are recovering from any medical condition or suffer from any mental or physical disability, you MUST seek professional medical advice before using this equipment.

Wear the correct Personal Protective Equipment for the task ahead.

Do not wear loose jewellery or clothing that may get in the way or become trapped in the equipment.

Do not cover this equipment or obstruct its air intake or outlet.

Inform everyone in the work area of what you are doing.

GET FAMILIAR! You must understand how to switch this machine OFF quickly in case of an emergency.



This equipment can weigh up to 29KG, do not attempt to lift it on your own, always get help.

Do not operate the unit in a confined space.

Do not move the unit by its power supply cable.


Always switch OFF the Industrial Cooling Fan and isolate it from the power supply before cleaning, making adjustments or when left unattended.

Carefully inspect the equipment before use, if there is any doubt about its condition, DO NOT USE IT.

ELECTRICAL SAFETY

The hirer is responsible for providing an adequate electrical supply on site for the amount of equipment being connected to the supply. Check the voltage is correct and that the supply can deliver the current required for the equipment (the power requirements of the equipment will be shown on its rating plate)

THE CONTROLS



The fan is fitted with an ON/OFF switch and a variable speed dial. Before switching the fan ON always set the speed to minimum, increasing as required once the fan is running.

DUST AND DEBRIS CONTROL


This machine will move any dust or light debris in its path when in operation. You must make sure that the fan is placed in a position where either dust is not present or will not be a nuisance.

Remember also that the fan will disrupt any paperwork and similar items.

POSITIONING THE FAN

Remove everything from the work area which may be disrupted by the airflow from the fan.

Position the fan on firm level ground, close enough the power supply.



Turn the unit so that the flow of air will be moved in the required direction then lock the thumbscrews.

Ideally, position the fan close to an open window where fresh air can be drawn in from outside. Make sure that there is a minimum clearance to the rear of the fan housing of 1m.

OPERATING THE FAN

Having positioned the fan, make sure that the unit is switched OFF then plug the unit into the power supply and switch the supply ON. The 'ON' indicator light will illuminate to show that it is connected to a live power supply.

Turn the variable speed ON/OFF switch clockwise to progressively increase fan speed as required.

When you have finished with the fan, set the speed to minimum before setting the ON/OFF switch to OFF.

NEVER operate the fan when on its side and never suspend the fan from a structure.

EQUIPMENT MAINTENANCE & CLEANING

When not being used, store the unit in a clean condition and in a safe place, away from thieves and unauthorised users.

FINALLY

When you have finished with the fan, turn the variable speed ON/OFF dial switch anticlockwise to OFF.

Once the fan has stopped rotating, unplug the unit from the power supply and neatly coil the cable. Give the unit a thorough clean ready for return.

NOTE

Failure to clean the equipment thoroughly may make you liable to a cleaning charge.